



USB TYPE-C ENCLOSURE FOR NVME PCIE M KEY M.2 SSD



EC-NVME / QUICK INSTALLATION GUIDE



EC-NVME / QUICK INSTALLATION GUIDE

FEATURES

- USB Type-C Enclosure for NVMe PCIe M Key M.2 SSD
- Compatible with Sizes: 2230 / 2242 / 2260 / 2280
- Compatibility Tested with:
Samsung 950 PRO / 960 EVO / PM951 / PM961 / SM951 / SM961
970 EVO / 970 PRO, and others

SYSTEM REQUIREMENTS


- Windows 7 or higher
- Mac OS 10.5 or higher

1
Remove screws



2
Remove bottom plate





WARNING: Only compatible with M Key M.2 PCIe NVMe SSD
It is **NOT** compatible with B Key SSD (SATA-based)
or the M Key M.2 SSD (PCIe AHCI-based)

3

At a 45-degree angle, slide in your SSD until it is properly seated



4

Screw in retainer screw to hold you SSD in place



5

Reattach bottom plate and fasten the screws in place



6

Connect USB cable to both the device and the computer



FOR HELP, COMMENTS, QUESTIONS OR CONCERNS
PLEASE CONTACT OUR TECH SUPPORT TEAM VIA OUR WEBSITE

WWW.SABRENT.COM